Unomat



Rest position Manual winding of the watch

Setting the Date

Setting the

Hour hand

●時計の巻き上げ:自動巻きムーブメントのおかげで、時計は着用すると自動的に巻き上げられます。ただし、時計を初めて着用する場合、またはしばらく着用していなかった場合は、リューズを少なくとも50回前後(リューズ位置:1)動かして時計を全巻き上げする必要があります。手巻き時計とは異なり、自動巻き時計は完全に巻き上げるとき、引っかかりを感じることはありませんが、時計のゼンマイを巻きすぎてムーブメントを破損させるようなことはございませんので、ご安心ください。

②日付の設定: 時計の日付が日中ではなく夜に切り替わるようにするには、まず時計が現在昼表示をしているのか、それとも夜表示をしているのかを確認する必要があります。このためには、リューズを3の位置まで引いて、日付切り替わるまで手前に回します。

日付が切り替わった瞬間、は真夜中の十二時です。 カレンダー機構を損傷しないように、 時計が午前2時以降に表示されるまで針を少し回します。 次に、リューズを2の位置まで押し、手前に回して現在の 日付を設定します。

③時刻を合わせる: リューズを一番外側(位置3)まで ゆっくりと引き、リューズを手前に回して時刻を合わせま す。シングルハンドウォッチの場合は、時刻は2分ごとに 表示されるため、そのまま2分間待つことをお勧めしま す。次に、リューズを慎重に押して元の位置に戻します。

※31日未満の月については何を考慮する必要がありますか?

カレンダーが切り替わるため、31日未満の月ではご自身で 日付を調整する必要があります。リューズを2の位置まで 引き、リューズを手前に回すと日付が切り替わります。 or Winding the watch: To set the watch, first unscrew the screwed crown by turning it towards you several times. The crown is unscrewed when it noticeably jumps to winding position 1a. Thanks to its automatic movement, your watch winds itself up when worn. However, when you wear your watch for the first time or if you haven't worn it for a while you should "charge" it by moving the crown back and forth approximately 30 times (position 1b). NB: Unlike hand-wound watches, you will not feel any resistance when your automatic watch is fully wound. But don't worry, it is not technically possible to overwind the spring of your watch.

o2 Setting the date: To ensure that the date of your watch jumps at night – and not during the day – you first need to find out whether your watch is currently showing day or night. For this, pull the crown to position 3 and turn it towards you until the date jumps. Now it is twelve o'clock midnight. Turn the hand a little further until the watch displays later than 2 a.m. so as not to

damage the calendar mechanism. Now press the crown to position 2 and turn it away from you to set the current date.

o3 Setting the time: Carefully pull the crown to the outer position 3. Turn the crown towards you and set the time. With your single-hand watch we recommend that you wait for the next full five minutes. Then carefully push the crown in and screw it tightly by turning the crown away from you while pressing it lightly.

What needs to be considered for months with fewer than 31 days?

As the calendar makes leaps, you need to adjust the date in months with fewer than 31 days. Pull the crown to position 2 and move the date on by turning the crown away from you.